



Additional installation guidelines for 3D screens packed in tubes

- Tube must be unpacked inside auditorium.
- Do not crush or bend tube.
- Place tube where there is at least double the length available – a 6m tube requires a minimum 12m clear space to unpack.
- Remove the packing from the end of the tube and check that all screws are removed from the open end of the tube.
- Draw the screen out carefully without putting any pressure on the screen.
- Ensure the screen is drawn level from the tube to prevent the end of the screen rubbing against the tube.
- Tension must be applied to the loose end of the screen, when the screen is being unrolled, to prevent the screen folding on itself, which could cause crease marks.
- Unwrap the screen and follow the installation instructions supplied.

www.harkness-screens.com